



QUALITY CLEANING SOLUTIONS



**IDEAL FOR:**

- Shops
- Carages
- Motels & Hotels
- Restaurants & Cafes

CB60 / CB80

**WET & DRY  
VACUUM CLEANER**



## IMPORTANT



Always switch off the cleaner and remove the plug from the electricity power supply before cleaning your appliance, when not in use. The cleaner must only be connected to an AC power supply at the voltage shown on the rating label. This cleaner should only be used for its intended purpose as described in this instruction manual.

**Never operate the vacuum cleaner without filters.**

## SAFETY PRECAUTIONS AND WARNING:

**WHEN USING YOUR VACUUM CLEANER, BASIC PRECAUTIONS SHOULD ALWAYS BE OBSERVED, INCLUDING THE FOLLOWING;**

1. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
2. Children should be supervised to ensure that they **do not** play with the appliance.
3. To prevent electrical shock, **do not** immerse the top cover of the appliance, power cord or power plug into water or other liquids.
4. To prevent electric shock, **do not** use the vacuum cleaner outdoors.
5. Always check the power cord before use, the power cord and the plug should be in a good condition and must not be damaged. If the power supply cord is damaged or defective, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
6. **Do not** unplug by pulling on the power cord. To unplug, grasp the plug not the power cord. Use only Australian and New Zealand electrical safety approved extension cords.
7. **Do not** pull or carry the appliance by the power cable, use the power cable as a handle or pull the power cable around sharp edges or corners.
8. Ensure the appliance is switched off before unplugging.
9. **Do not** handle or operate the appliance with wet hands and follow electrical safety precautions at all times.
10. Extreme caution should be exercised when using the appliance on stairs.
11. **Do not** attempt to change the attachments while the appliance is plugged in to Mains power supply. Switch off and remove plug from Mains power supply. Use only manufacturer's recommended accessories.
12. **Do not** operate the vacuum cleaner too close to heaters, radiators and other hot surfaces.
13. **Do not** use the appliance to pick up flammable items or combustible liquids (i.e. gasoline, hot ashes cigarettes, matches, explosive materials or anything burning) or use in areas where such substances and items may be present.
14. **Do not** use the appliance to pick up toxic materials (i.e. chlorine bleach, ammonia).
15. Ensure the appliance is disconnected from the Mains power supply before connecting the hose to the unit.
16. Before vacuuming, remove any large or sharp objects from the floor or cleaning surface in order to prevent damage to the filter.
17. If the air inlet, floor head or the telescopic tube is blocked, switch off the cleaner straight away and remove from the Mains power. First clear the blocked object before attempting to start the cleaner vacuum again.

18. **Do not** leave the appliance unattended when it is connected to a Mains power supply.
19. Before carrying out any maintenance service or cleaning the filters, always switch off the vacuum cleaner and disconnect the plug from power supply.
20. Keep ends of the hose, telescopic tube and other openings away from your face and body.
21. **Do not** use the vacuum cleaner if it is damaged or breaks down. Check the electrical regularly for defects. If connection cables, electrical hoses, electrical contacts and electrical tubes are damaged, have them replaced immediately.
22. Never clean any of the electrical parts, especially the electrical connections with water or liquid cleaners.
23. Never attempt to make any modifications electrically to the vacuum cleaner.
24. Always store the appliance indoors in a cool and dry place.
25. For indoors use only.
26. Damage caused by improper use or by not observing the instructions in this manual will void warranty.

## BEFORE YOU BEGIN



1. **Do not** operate the vacuum cleaner too close to heaters, radiators, cigarette butts etc.



2. Before you insert the plug into the Mains power supply, make sure your hand is dry.



3. Before you start using the Backpack, please remove large or sharp objects from the floor in order to prevent the paper filter being damaged.



4. When you remove the plug from the Mains power supply, please do this at the plug itself and not by the electrical cable.



5. **Do not** use Backpack to pick up water or liquids.

**THIS MACHINE IS EQUIPPED WITH A CORD AND PLUG. IN THE EVENT THAT EITHER OF THESE PARTS GET DAMAGED, IT MUST BE REPAIRED BY A QUALIFIED TECHNICIAN.**



## KNOW YOUR PRODUCT

1. Lid Handle
2. On/Off Switch
3. Tank
4. Hose Inlet
5. Hose
6. Castor Wheels
7. Drain Hose
8. Cord Holder
9. Connection Latches
10. 2 Piece Metal Tube
11. Carry Handles
12. Dry Pick Up Tool  
(hard floor only)
13. Wet Pick Up Tool
14. Crevice Tool
15. Dusting Brush

### Technical Information

Model: CB60  
220-240V~ 50Hz  
2000W

Model: CB80  
220-240V~ 50Hz  
3000W



# ASSEMBLY

## Assembling the Hose and Floor Tools

**ALWAYS SWITCH OFF YOUR BACKPACK AND REMOVE THE PLUG FROM THE MAINS POWER SUPPLY BEFORE CLEANING YOUR APPLIANCE, ASSEMBLING, WHEN NOT IN USE OR ATTEMPTING ANY MAINTENANCE TASK.**



1. Connect the 2-piece metal tube together.



2. Connect the handle on the hose to the tube.



3. Connect the tube to the desired cleaning accessory.



4. Connect the hose to the Pullman CB60.

## ACCESSORIES



### DRY PICK UP FLOOR TOOL

The dry pick up floor tool is ideal for vacuuming hard floors.

Do not use the dry pick up floor tool on carpets.



### WET PICK UP FLOOR TOOL

The wet pick-up tool is ideal for wet applications.



### FITTING DUSTING BRUSH AND CREVICE TOOL

To fit the accessories to the 2 piece metal tube, gently insert the tube into the top of the dusting brush or crevice tool.

Dusting Brush - ideal for cleaning furniture, curtains and upholstery

Crevice Tool - ideal for cleaning in tight spaces

# INSTRUCTIONS FOR USE

## IMPORTANT: DISCONNECT THE CLEANER BEFORE CHANGING ACCESSORIES OR TO EMPTY THE CLEANER.



Before turning on the Pullman CB60 Vacuum Cleaner, please check that the Drain Hose is secure to the tank and the cap is fully closed.



### Dry Vacuum Cleaner

1. Release the connection latches to remove the canister lid.



2. Ensure the cloth filter bag is always installed before dry use.



3. Turn the switch of the vacuum cleaner to position "I".

4. You can determine the suction by using either 1 or 2 motors. Each motor is controlled by a switch located on the front.

5. Empty the dust tank or dust bag when it's full or after each use.

6. The cloth filter also needs to be cleaned accordingly.



## TROUBLESHOOTING

TROUBLE	POSSIBLE CAUSE	REMEDY
Suction weakens or Cleaner runs hot	Clogged filter	Brush dirt from filter. If condition continues, change filter.
	Air leak	Check all fittings for tight fit (floor tool, hoses, etc.). Check that tank cover is sealed properly.
	Obstruction in hose or floor tool	Check floor tool, hose, etc. For obstructions, and remove if present.
Misting in the exhaust air	Saturated filter	Replace saturated filter and the filter mesh.

## Specification

Model: CB60-SS

Voltage: 220V-240V~ 50Hz

Watts: 2000W

Function: Wet & Dry

Volume: 60L

Cable: 8m

Net Weight: 24.5KG

Gross Weight: 27.5KG

Model: CB80-SS

Voltage: 220V-240V~ 50Hz

Watts: 3000W

Function: Wet & Dry

Volume: 80L

Cable: 8m

Net Weight: 26.7KG

Gross Weight: 30.2KG



# SPARE PARTS

Please contact Godfreys Commercial Customer Support on 131 929 to find your local spare parts provider.

PRODUCT NUMBER	PRODUCT DESCRIPTION
33500316	Small Castor Wheels
33500315	Rear Wheels
33200523	On/Off Switch
31110125	Dry Pick Up Floor Tool (OPTIONAL)
31150248	Wet Pick Up Floor Tool 40mm
31150014	Dry Pick Up Floor Tool 40mm
31220267	Hose Assembly 40mm
31300392	2-Piece Chrome Tube
31130061	Dusting Brush 40mm
31120070	Crevice Tool 40mm
33701473	Float Cage
33400126	Cloth Filter
33101028	Pipe, Drain Assembly
33101026	Trolley Base



## NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



## Conditions of warranty



Your Pullman cleaner, in the case of domestic use, has a one year warranty against product defects and failures when the product is used in accordance with the terms and conditions of this warranty statement.

This warranty is provided by Future Innovation Holdings Pty Ltd Trading as Godfreys Commercial ABN 98 677 632 021. This warranty commences from the original date of purchase and is not transferable. You are required to retain your original proof of purchase for any claims under this warranty. This warranty is valid only in the country where the cleaner is purchased.

Your Pullman cleaner must be operated in accordance with these instructions and used only for domestic household cleaning to remove dry dirt and dust from household carpets, flooring and fabrics. Your Pullman cleaner is not fit to be used as an industrial cleaner, and is not designed for the collection of vitreous building material including particle board, construction products and similar products such as wood/ fibres, cement, fillers, fibre glass etc or excessive or frequent sand. The infrequent pick-up of these materials may be harmful to your cleaner and will void this warranty.

Accessories and consumables including dust bags and filters, unless defective in manufacture, are not subject to this warranty. In order to prolong the life of accessories and consumables, regular care and maintenance is recommended.

Refer to the instruction manual for further regarding the use and care of your Pullman cleaner, as misuse or failure to follow the instructions voids this warranty.

In the event of service or advice being needed, or if you would like to make a claim under this warranty, please immediately stop using the Pullman cleaner and contact Godfreys Commercial, 2 Drake Boulevard Altona, VIC 3018 on 131 929, Monday-Friday 9am-5pm AEST or [commercialsupport@godfreys.com.au](mailto:commercialsupport@godfreys.com.au).

The decision to repair or replace the cleaner is at the discretion of Godfreys Commercial depending on the circumstances and requirements of any applicable law. If Godfreys Commercial decide to repair or replace your Pullman cleaner, it will do so at its own cost. Any transportation costs involved in a claim under this warranty shall be borne by the claimant.

Godfreys Commercial is unable to accept responsibility under this warranty for any repair work not carried out by an authorised Service Agent, or any defect arising from or in connection with the use of non-genuine parts. If any part is no longer available or manufactured, Godfreys Commercial will replace it with a genuine functional replacement part. This warranty does not apply to the cost of replacing any parts of the Pullman cleaner due to normal wear and tear, alterations, improper installation, physical abuse, misuse or accidental damage.

If proof of purchase cannot be provided at the time of a warranty claim or service, any work carried out on the Pullman cleaner will be at claimant's cost.

The repair of the Pullman cleaner under this warranty does not extend the original period of warranty. If your Pullman cleaner is replaced under this warranty, the replacement will be covered by this warranty for the remainder of the original warranty period. However, you may still have statutory rights after this time.

The benefits conferred by this warranty are in addition to all other rights and remedies in respect of the product as outlined under the Competition and Consumer Act 2010 (Cth) and other State and Territory laws.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.



**Future Innovation Holdings Pty. Ltd. trading as Godfreys Commercial**

ABN: 98 677 632 021

2 Drake Boulevard Altona, Victoria 3018

**Customer Support:**

131 929

[www.godfreyscommercial.com.au](http://www.godfreyscommercial.com.au)

[commercialsupport@godfreys.com.au](mailto:commercialsupport@godfreys.com.au)

Pullman® is a registered trademark.